## Dell UltraSharp 40 Curved WUHD Monitor-U4021QW Dell Display Manager User's Guide





NOTE: A NOTE indicates important information that helps you make better use of your computer.

Copyright © 2020 Dell Inc. or its subsidiaries. All rights reserved. Dell, EMC, and other trademarks are trademarks of Dell Inc. or its subsidiaries. Other trademarks may be trademarks of their respective owners.

2020 - 12

Rev. A00

### Contents

Overview
Using the Quick Settings Dialog
Setting Basic Display Functions
Assigning Preset Modes to Applications
Organizing Windows with Easy Arrange
Managing Multiple Video Inputs
Restoring Application Positions
Applying Energy Conservation Features
Other Shortcut Keys15
Attach DDM To Active Window (Only Window 10) 16
Troubleshooting

(D&LL

#### Overview

Dell Display Manager is a Microsoft Windows application used to manage a display or a group of displays. It enables manual adjustment of the displayed image, assignment of automatic settings, energy management, window organization, image rotation, and other features on selected Dell displays. After installed, Dell Display Manager runs each time the system starts and places its icon in the notification tray. Information about displays connected to the system is available when hovering over the notification-tray icon.



NOTE: Dell Display Manager uses DDC/CI channel to communicate with your display. Ensure that DDC/CI is enabled in the menu as below.

<b>6</b> 54	UltraSharp 40 Monitor		
÷¢:	Brightness/Contrast		
	Input Source		
	Color		
ç	Display		
	PIP/PBP		
Q	USB	Off	
	Audio		
	Menu		
	Personalize		



### Using the Quick Settings Dialog

Clicking Dell Display Manager's notification tray icon to open the **Quick Settings** dialog box. When more than one supported Dell displays are connected to the computer, a specific target display can be selected using the menu. The **Quick Settings** dialog box enables convenient adjustment of the display's brightness, contrast, resolution, window layout, and so on. You can select **Manual Mode** or **Auto Mode**, and the screen resolution can be changed.

(ca) Display	Hanagar	5
Digitize	Del LHIZ IGN	
Repolutions.	St 2002 MG	Change
C Auto Made		Carloure
🛞 Hanad Hade	Standard	~
Projetnem		706
Contract	<mark>.</mark>	700.
×		
E ===		>
	Open Ciel Chiples Manager	

The **Guick Settings** dialog box also provides access to Dell Display Manager's advanced user interface that is used to adjust basic functions, configure auto mode and access other features.

#### MOTE:

Feature	Function	Description
Quick DDM Access	Quick key to call up DDM UI	<ul> <li>Ctrl+Shift+D</li> <li>Use Page Up/Page Down key or click on "&gt;" to flip through all Easy Arrange layouts.</li> </ul>
	Control individual display in multiple display setup	<ul> <li>From dropdown box to select display, selected display has Dell logo shown.</li> <li>Perform display self-test feature check.</li> <li>Move DDM UI to the display to be controlled.</li> <li>Press Ctrl+Shift+D to bring up the miniUI under the mouse pointer.</li> </ul>



5

#### **Setting Basic Display Functions**

You can select **Manual Mode** that enables you to manually select a preset mode or select **Auto Mode** that applies a preset mode based on the active application. An onscreen message displays the current preset mode whenever it changes. The selected display's **Brightness** and **Contrast** can also be directly adjusted from the **Basic** tab.

Base	- 1967 - 1960 -	Classify any	Casel Midlinger,	Sellen -	1
acadatece .	- Contra				and i
C LIBASA UH DHHS	oor antronearder for	etre sociatore		87	her.
00 menai hobi Cisso spri	ve. : wa		Rece.		
land's mate			99		
All setting			25		

NOTE: When multiple Dell displays are connected, select "Enable display matrix control" to apply brightness, contrast and color presets controls to all displays.

a). Chienny	Weater :			1010	998 H
Ast.	A.2-764	-102/058	Egist Norman	3500	
(datas)	$h \gg_{0} h / h$			- (5	hotor
and the second secon	on an communitor s	nie agriation		2	der:
Of these disest Change at the	ac sea		Starter;		
OWTHE!	-		20		
Co-dead			200 200		
-	and a state				

6 | Setting Basic Display Functions

DELI

#### **Assigning Preset Modes to Applications**

The **Auto Mode** tab allows you to associate a specific **Preset Mode** with a specific application, and apply it automatically. When **Auto Mode** is enabled, Dell Display Manager automatically switches to the corresponding **Preset Mode** whenever the associated application is activated. The **Preset Mode** assigned to a particular application may be the same on each connected display, or it can vary from one display to another.

Dell Display Manager is pre-configured for many popular applications. To add a new application to the assignment list, simply drag the application from the desktop, Windows Start Menu, or elsewhere, and drop it onto the current list.

#### NOTE: Preset Mode assignments for batch files, scripts, loaders, and nonexecutable files such as zip archives or packed files, are not supported.

You can also configure the Game preset mode to be used whenever a Direct3D application runs in full-screen mode. To prevent an application from using mode, assign a different preset mode to it.

Sec.	de las factor	Tes (Alamati	Intel Herman	Oelana -	
Cody in the second	the design of the spirit	das Lincia g	phane, ang the bolt	90 - C	
ectorics.		(3 <b>766)</b> (5	206		1.0
T Deine	he vertiles and	19-292	4 + -		
S. Calu	for the second state $\langle T_{ij}^{*}\rangle$	(Sec.)			
di seba	to inclusion involves to	eo - 462			
S solo	H.I	. 002			
B bereinet	Radores	(952)			
() lives	1.0	10.00			124


#### **Organizing Windows with Easy Arrange**

**Easy Arrange** helps you to effectively organize your application windows on the desktop. You first choose a pre-defined layout pattern which suits your work, then you just need to drag the application windows into the defined zones. Press ">" or use Page Up/Page Down key to find more layouts. To create a custom layout, arrange the open windows and then click **Save**.



For Windows 10, you can apply different window layouts for each of the virtual desktops.

If you often use Windows snap feature, you can select "**Hold down the SHIFT key to enable zone positioning**". This gives Windows snap priority over **Easy Arrange**. You will then need to press the Shift key to use **Easy Arrange** positioning.



If you are using multiple displays in an array or matrix, **Easy Arrange** layout can be applied across to all the displays as one desktop. Select "**Span multiple displays**" to enable this feature. You need to align your displays properly to make it effective.



There are other advanced ways for the usage of Easy Arrange. Refer to table below.

Feature	Function	Description
Enhanced Easy Arrange	Custom layouts	<ul> <li>Save and name 5 customized Easy Arrange patterns.</li> <li>Configure x*y patterns.</li> </ul>
	5 MRU (most- recently-used) layouts	<ul> <li>Press Ctrl+Shift+Home to cycle among the last 5 MRU layouts.</li> </ul>
	On the fly parti- tion resizing	<ul> <li>Hold down Ctrl while resizing current Easy Arrange layout to adjust the size and numbers of cells in a layout.</li> <li>Newly formed Easy Arrange pattern is saved into the Easy Arrange icon position.</li> <li>Hold down Ctrl while clicking on a modified layout icon to restore it to default layout.</li> </ul>
	<b>Easy Arrange</b> layouts for portrait mode	<ul> <li>Portrait mode Easy Arrange icons are presented when display is rotated.</li> </ul>

NOTE: An application may require a minimum effective resolution for its application window. Such application may not fit in an Ease Arrange zone if the zone is smaller than the required window size.

### Managing Multiple Video Inputs

The **Input Manager** tab provides convenient ways for you to manage multiple video inputs connected to your Dell display. It makes it very easy to switch between inputs while you work with multiple computers.

All video input ports available to your display are listed. You can give each input a name as you like. Please save your changes after editing.

You can define a shortcut key to quickly switch to your favorite input and another shortcut key to quickly switch between two inputs if you often work between them.

26	La puncto de la la la composición de la	i Doutine	22	122223
en in solit	AND AND A	2.5. 60 500	1.997	
Produity (R	(Club in will)	COM-	10.00	
P (Marel	(Although and C	10-000	10.0	_
eve.	ji kitar otoj	Street	CONT	
947) 	7.502 N 466	estat.	ाम	
- 1997 - S	- Official -			1646
And a second second	11 (127)	1.00	10.000	20.00 PM 00.0

You can use the PIP/PBP mode to adjust PIP Size of Small and Large, PIP sub-window position, PBP 2 window.

	Ľ	PIP Size Small/Large
PIP	$ \begin{array}{ c c c c c c c c c c c c c c c c c c c$	PIP sub-window position, Top-Left, Top-Right, Bottom-Right, or Bottom-left.
	80%	
PBP	80%	PBP 2 window
	75%	
	75%	

Dell

Sec.	de la contraction	Para Leverge	10.010	No.	Typices	1.19
South participants	<b>by</b> al iy		CPI spalese	n ar b		
Treesee	(3.4.5)	dit -	Classer .	0.00		
ie .	23.4.16	add _	4.004	10mm		
1001	25.16	كبله	- (+ . A.A.A.	Cor.		
1961)	346	C la	# 25.6	-0.77		
		100 LS	8 103	100	12	
National I		New York The		1.10 million	and had been	
6×		hardelard.	+	4.90		
tal index of 1		A station of the		interaction Design	detectory -	

In case two inputs need to swap their window positions, 'Video swap' button provides a set of defined pairs for quick selection.

livit.	A Printedo	Fang Lowege	10.010	alar 👘	Typices	11
Soul parts	Reput your		CR spales	n art.		
Distant	().e.s.:	45	0.004	6.17		
99 1	23.3.19.1	84	40.000	Cont		
1000	Station		40.000	(Corr.		
1990)	30. is a	a)	# 254	City,		-
	<b>6</b> 88		a ins	1775	12	
Noter State		ul resolution tax		1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	a distant	
6×		10.00 Million		1.00		
Tablighting 1		Contraction of the	_	index percent from the	detections.	

You can use the dropdown list to switch to any input source.

linini, com	+ this international frequencies	KO/Phoe	63 E.S.	Orderet	
New year of	App	1.05 pair any			
Provinsio	NAK N WAL	Charge .	gent.		
a second	KILL N WHE	\$105	0.00		
091	STAL In whit	\$102	-0.09°		
1963	(Chile for young)	Sec	1244		
<b>20</b> 200 10	an a maria ang ang ang ang ang ang ang ang ang an		1	3.4	
			1000		
langelike inter di sindelik Name ()	22 BAPT	14		an average states in a	

NOTE: DDM communicates with your display even when the display is displaying video from another computer. You can install DDM on the computer you frequently use and control input switching from it. You may also install DDM on other computers connected to the display.



#### **Restoring Application Positions**

DDM can help you restore application windows into their positions when you reconnect your computer to the display(s). You can quickly access to this feature by right-clicking on DDM icon in the notification tray.

Hum Hill Daily Manager —
Analysis and a states
See to reliable to type
Be more some dissipations inner a
Calve information days hypoth
And the deep second loss
Clerk, by the constant
Dek.

If you choose "**Auto-restore window layout**", your application windows' positions are tracked and remembered by DDM. DDM automatically puts the application windows into their original positions when you reconnect your computer to your display(s).

Open Dell Digity Mangel Aradh ta bio ta Airdea
Seconda es di sonsias ayant Ranso proventi eli della legista Accordante el eli della legista
C de altors en tras e. Chablishen visitera tal

If you want to go back to a favorite layout after you have moved the application windows around, you can first "Save current window layout" and later "Restore saved window layout".

Open Dell Display Manage
Araidh to sidh ta Airdole
Several content window layout
Tarte wave diversity before
Actor rations with the lighter
S de relevas en de as se
Checklor nen verden
bal .

You may use displays with different models or resolutions in your daily routine, and you may apply different window layouts on them. DDM is able to know the display you have reconnected and restore application positions accordingly.

In case you need to replace a display in a display matrix configuration, you can save the window layout before replacement and restore the layout after a new display is installed.

# NOTE: You should keep your applications running in order to benefit from this feature. DDM doesn't launch applications.



#### **Applying Energy Conservation Features**

On supported Dell models, an Options tab is available that provides PowerNap energy conservation options. You can choose to set the display's brightness to the minimum level, or to put the display to sleep when the screensaver is activated.





#### **Other Shortcut Keys**

Shortcut keys can be defined for below operations, you can define the shortcut keys for quick access to perform these operations:

- Program shortcut key: to quickly open the Quick Settings dialog box.
- Easy Arrange MRU shortcut key: to quickly apply the 5 recently used window layouts.
- Application window shortcut key: to launch a quick menu for options under Auto Mode and Easy Arrange.
- **PIP position shortcut key:** to quickly apply the PIP sub position of window position of Top-Left, Top-Right, Bottom-Right or Bottom-left.

(m) ===	W Clarager			000000000
- Ball	4/6/702	Two hierges	Trout Parage	Tyles 🛛 🕹
E Paladha C Paladha C Paladha	galapani Alapitan kalani jerra Alapitan ka-dama-dami			Differe
Ctrl + shift Ctrl + shift Ctrl + shift	+ Num 2 + Num 4 + Num 5		atan anna argita	]



#### Attach DDM To Active Window (Only Window 10)

DDM icon can be attached to the active window you are working on. Click on the icon for easy access to below features.

Feature	Function	D	Description
Attach DDM to Active Window (only Window	Change preset or snap to different partitions	•	DDM icon attached to active window and user can easily switch windowposition, change color preset mode, and associate auto preset mode.
10)	Shortcut key trigger	٠	On a running app window, press Ctrl+Shift+Ins also trig- gers the attached DDM menu.
	Move app window among <b>Easy Ar-</b> range cells		Send the app window to previous/next <b>Easy Arrange</b> cell.
	Move app window among displays	•	Send the app window to previous/next display.



DELL

#### Troubleshooting

If DDM does not work with your display, DDM will show below icon in your notification tray.



Click on the icon, DDM shows a more detailed error message.



Please note that DDM only works with Dell branded displays. If you are using displays from other manufacturers, DDM doesn't support them.

If DDM is unable to detect and/or communicate with a supported Dell display, please take below actions to troubleshoot:

- 1. Make sure the video cable is properly connected to your display and your computer. especially the connectors should be firmly inserted into position.
- **2.** Check the display OSD to ensure DDC/Cl is enabled.
- **3.** Make sure you have the correct and latest display driver from the graphics vendor (Intel, AMD, NVidia, etc.). Display driver is often the cause of DDM failure.
- **4.** Remove any docking stations or cable extenders or converters between the display and the graphics port. Some low-cost extenders, hubs or converters may not support DDC/CI properly and can fail DDM. Update the driver of such device if the latest version is available.
- 5. Restart your computer.

DDM may not work with below displays:

- Dell display models earlier than year 2013 and D-series of Dell displays. For more information see www.dell.com/support/monitors.
- Gaming displays using Nvidia-based G-sync technology
- · Virtual and wireless displays do not support DDC/CI
- Some early models of DP 1.2 displays, it may be necessary to disable MST/DP 1.2 using the display OSD

If your PC is connected to the Internet, you will be prompted to upgrade to a newer version of DDM when it is available. It is recommended to download and install the latest DDM application.

You may also check for new version by right clicking on DDM icon while pressing and holding 'shift' key.

	Open Dell Display Manager
	Refresh.
	Save monitor asset report
	Save diagnostic report
	Seve current window layout
	Rectore saved window layout
	Auto-nextone window layout
	Auto-load at startup
1	Onscreen notifications
	Check for new version
	Edt