




















VORTEX LUM 360


MANUAL

ACCESSORIES


A  Intel Backplate x1	B  Intel Backplate x2	C  AMD Backplate x2	D  Backplate x2
E  x4	F  x4	G  x4	H  x12
I  x4	J  x12	K  x1	L  x1
M  x1	N  x1	O  x4	P  AMD TR4 Backplate x2
Q  x4	R  x3	S  x1	

INTEL PLATFORM INSTALLATION


Intel 115X / 1200 / 1700 / 1851




Intel 115X / 1200



Intel 1700 / 1851




Intel 20XX




AMD PLATFORM INSTALLATION



AMD AM3 / AM4 / AM5





AMD TR4





INSTALL THE PUMPHEAD & FAN



RADIATOR INSTALLATION



CONTROLLER



Antec
BELIEVE IT

www.Antec.com

All rights reserved. Specifications are subject to change without prior notice. Actual products and accessories may differ from illustrations. Omissions and printing errors excepted. Content of delivery might differ in different countries or areas. Some trademarks may be claimed as the property of others.