

Quick Start Guide

G416

AX1500 4G+ SMART ROUTER



x1




x1




x1



1 /



2 /




<https://eu.dlink.com/support>




OPTION 1

3 /




4 /



OPTION 2

3 /

Wi-Fi Name (SSID): G416-XXXX
Wi-Fi password: XXXXXXXXXX



4 /

<http://xxxx.devicesetup.net/>
Device Password: XXXXXX

