



4



Register your product and get support at
www.philips.com/support



FAQ

Software
SmartControlUser
Manual

Energy Labelling

24E1N1300AE 24E1N1300AM



27E1N1300AE 27E1N1300AM



27E1N1600AE 27E1N1600AM



Printed in China



F41G24M181341C----

Version: 2XE1N1X00EQ1L

2023 © TOP Victory Investments Ltd. All rights reserved.

This product has been manufactured by and is sold under the responsibility of Top Victory Investments Ltd., and Top Victory Investments Ltd. is the warrantor in relation to this product. Philips and the Philips Shield Emblem are registered trademarks of Koninklijke Philips N.V. and are used under license.

Specifications are subject to change without notice.

HDMI®

The terms HDMI, HDMI High-Definition Multimedia Interface, HDMI Trade Dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.

www.philips.com
PHILIPS

Monitor



1000 Series


 24E1N1300AE
 27E1N1300AE
 27E1N1600AE
 24E1N1300AM
 27E1N1300AM
 27E1N1600AM


Quick Start

 Register your product and get support at www.philips.com/welcome


Contents



Screwdriver




Power




HDMI



USB C-A



USB C-C



USB C-C/A

EN The images shown are for illustrative purposes only. Actual product and accessory may vary by country or regions. Actual product and accessory shall prevail in kind.

SC 所有插图和产品配件仅为示意参考。因销售区域差异，产品可能不含有以上配件，具体以实物为准。


FR Les images sont uniquement fournies à des fins d'illustration. Le produit et les accessoires actuels peuvent différer selon le pays ou la région. Le produit et les accessoires réels prévaudront dans tous les cas.

JP 表示されている画像は説明のみを目的としています。実際の付属品は国や地域によって異なる場合がございます。

ES Las imágenes que se muestran son solo de carácter ilustrativo. El producto y los accesorios reales pueden variar según el país o las regiones. El producto real y el accesorio prevalecerán en especie.


KO 표시된 이미지는 이해를 돕기 위한 것으로 실제 제품 및 액세서리는 국가 또는 지역에 따라 다를 수 있습니다. 실제 제품 및 동봉된 액세서리를 확인하세요.

1




▲ CAUTION: Place the monitor face down on a smooth surface. Pay attention not to scratch or damage the screen.


2




USB C-C




USB Type-C





USB hub (USB A-C)



USB Type-A



3


 24E1N1300AE
 27E1N1300AE
 24E1N1300AM
 27E1N1300AM:
 Input
 HDMI 1.4
 USBC

 27E1N1600AE
 27E1N1600AM:
 Input
 HDMI 2.0
 USB C


 SmartImage
 EasyRead
 Office
 Photo
 Movie
 Game
 Economy
 LowBlue Mode
 Off

 27E1N1600AE
 27E1N1600AM:
 SmartImage™
 HDR Vivid
 HDR Movie
 HDR Basic
 Personal
 Off


Volume - 80 +



Game Setting	Adaptive Sync	Off
LowBlue Mode	MPRT	On
Input	MPRT Level	0
Picture	SmartResponse	Off
Audio		
Color		



Game Setting	Adaptive Sync	Off
LowBlue Mode	MPRT	On
Input	MPRT Level	0
Picture	SmartResponse	Off
Audio		
Color		



Game Setting	Adaptive Sync	Off
LowBlue Mode	MPRT	On
Input	MPRT Level	0
Picture	SmartResponse	Off
Audio		
Color		



Game Setting	Adaptive Sync	Off
LowBlue Mode	MPRT	On
Input	MPRT Level	0
Picture	SmartResponse	Off
Audio		
Color		