


XXXXXXXXXXXX




DROPPING DANGER


DO NOT TILT!
NIET KANTELEN!
NE PAS INCLINER!
NICHT KIPPEN!
NON INCLINARE!
NO INCLINAR!





3. Android



HOME + A





4. PC - X-input



HOME + X

5. PC - Direct Input



HOME + B