# **Dell Display Manager on Mac** User's Guide





NOTE: A NOTE indicates important information that helps you make better use of your computer.

Copyright © 2021 Dell Inc. or its subsidiaries. All rights reserved. Dell, EMC, and other trademarks are trademarks of Dell Inc. or its subsidiaries. Other trademarks may be trademarks of their respective owners.

2021 - 09

Rev. A00

# Contents

Overview	5
Downloading and setting up the Dell Display	
Manager	6
Downloading Dell Display Manager	. 6
Connect your monitor to your Mac	. 6
Before launching Dell Display Manager	7
Using the Quick Settings dialog	8
Launching Dell Display Manager	10
Setting basic display functions	11
Assigning preset modes to applications	13
Organizing windows with Easy Arrange	14
Using Application Window Snap	16
Managing multiple video inputs	17
Selecting PIP/PBP mode	18
Setting up the KVM	19
Applying energy conservation features	23
Other shortcut keys	24
Restoring application positions	25
Troubleshooting	27
Dell monitors not supported by Dell Display Manager	27

(Dell

Unable to detect supported Dell monitor	27
Updating Dell Display Manager software	29

Deell

#### Overview

Dell Display Manager (DDM) is an Apple macOS application used to manage a monitor or a group of monitors.

Dell Display Manager allows manual adjustment of the displayed image, assignment of automatic settings, energy management, window organization, image rotation, and other features on selected Dell monitors.

After installing Dell Display Manager, it runs each time your system starts. A quick access icon is available in the status menu, with information about connected monitors available when you hover your cursor over the icon.



- NOTE: Some hardware-dependent features are only available on monitors that support those features. Refer to your monitor's user guide for information about which features are available.
- NOTE: Screenshots in this document are for illustrative purposes only. Some features may not be supported by your monitor.

Déi

#### Downloading and setting up the Dell Display Manager

#### Downloading Dell Display Manager

Browse for your monitor or type it in at **https://www.dell.com/support**. Download Dell Display Manager for Mac from the list of downloads, and install it on your Mac.

#### Connect your monitor to your Mac

1. Connect your Mac to monitor as described in your monitor's user's guide.



- NOTE: Connectivity diagrams are for illustrative purposes only. Refer to your monitor's user's guide for complete information about connecting your monitor.
- NOTE: Ensure that the USB Type-C cable or USB upstream (USB Type-B) cable is connected between your Mac and your monitor.

DELI

### Before launching Dell Display Manager

Before launching Dell Display Manager, go to **Others** in your monitor's On-Screen Display menu and ensure that the **DDC/CI** feature is enabled.



When launching Dell Display Manager for the first time, the application will request access to **Screen Recording and Accessibility** privileges on your Mac.

Click **Open System Preferences** and follow the on-screen instructions to enable **Screen Recording** and **Accessibility**.



NOTE: Screen Recording and Accessibility privileges must be granted in order for Dell Display Manager to launch on your Mac.

DEL

# Using the Quick Settings dialog

Clicking Dell Display Manager's icon on the status bar opens the **Quick Settings** dialog box. When multiple Dell monitors are connected to the computer, you can select any monitor from the drop-down menu.

The **Quick Settings** dialog box provides quick access to commonly-used features, such as configuring the monitor's:

- Resolution
- Brightness and Contrast
- · Presets (auto or manual mode)

A list of recently-used layouts are available for quick selection. Click on the **More Options** to access other layouts from the **Easy Arrange** tab in the Dell Display Manager interface.

E top lity	Ov 1	
Rostuke	2560 × 1000	Otarge
CARDIN		12 million and
🔷 9 ar se 19 co	£	Standard
e a provinsi.		
Carager		- 42
foresti se f		Macropher
122		

NOTE: Dell Display Manager matches customized System Preferences applied on your Mac.



DELI

Feature	Function	Description
Quick DDM Access	Shortcut key to launch <b>Quick</b> Settings dialog box	• Ctrl+Shift+D
	Select monitor when multiple	<ul> <li>When more than one monitors are connected to the computer, select the monitor from the model drop-down list to configure the monitor.</li> </ul>
monitors are connected	<ul> <li>When the monitor is selected from the UI, the selected monitor screen will be dimmed momentary, showing a monitor icon with the model name on the screen to indicate the physical screen selected.</li> </ul>	
		<ul> <li>Press Ctrl + Shift + D to bring up the Quick Settings dialog box of the monitor where the mouse pointer is currently located.</li> </ul>

(D&LL

### Launching Dell Display Manager

Launch the Dell Display Manager by one of the following methods:

• Right-click on the DDM icon on the status bar and select **Open Dell Display Manager...** 



· Click Open Dell Display Manager from the Quick Settings Dialog box.

Display	05 S	
Resolution	2550 × 1000	O m ge
CAUSERIA.		Eteriore
🗿 9 artas Med		Standard
e against a		
Carryon		er.
feedbood.		Machaele
123		HO IGH

#### Setting basic display functions

In Dell Display Manager menu, access the **Basic** tab to change the basic functions.

Feature	Function	Description
Basic	Resolution	Change screen resolution.
	Auto Mode	<ul> <li>Click on the <b>Configure</b> button to access the Auto Mode tab to assign a preset mode to an application.</li> </ul>
		<ul> <li>Enable this feature to activate the preset mode automatically when the associated application is selected as the active window.</li> </ul>
	Manual Mode	Select the preset mode manually from the user interface.
	Brightness / Contrast	Adjust the monitor's brightness and contrast.
	Enable display matrix control	<ul> <li>Enable this feature to allow you to apply the brightness, contrast and color presets controls to all connected supported monitors.</li> </ul>

# NOTE: "Enable display matrix control" is active when multiple monitors are connected



Single monitor connection user interface



Multi-monitor connection - Enable display matrix control

# Assigning preset modes to applications

The **Auto Mode** tab allows you to associate any **Preset Mode** with an application. When **Auto Mode** is enabled on the **Basic** tab, Dell Display Manager automatically switches to the corresponding **Preset Mode** whenever the associated application is activated. The **Preset Mode** assigned to a particular application may be the same on each connected monitor, or it can vary from one monitor to another.

To add a new application to the assignment list, go to finder to search for the application, drag it from the Finder and drop to the current list. Choose the preset from the **Preset Mode** drop-down list to associate the preset to the application.

NOTE: Preset Mode assignments for batch files, scripts, shortcuts, and non-executable files such as zip archives or packed files, are not supported.

waigh a president character back of	perific apply that. At add or legitlation, stop	ALC: NOTE NO.
hameter:	Preset Made	
	Standa d	
Terminat	03028	8
Resde -	66009	8
Adridee Photoschuip 2027	Mave	
bea t	Canton	8



# Organizing windows with Easy Arrange

The **Easy Arrange** tab simplifies the applications window organization on the monitor. To use it:

- **1.** Select any of the predefined layout to virtually divide the screen into multiple zones.
- **2.** Drag the application to your selected zone to position the application in the zone. The application will snap to the selected zone.

Click the > icon to explore more layouts. To create a custom layout, arrange the application zone positioning by resizing the zone for the opened windows and then click **Save** to save the layout as custom layout.

	Sel Dripley Variage:
Area Area base Salari a paint francisco a succeso atom and success of another and enter at	A layout for this section. Open schemes at agget total section.
×	
To reads a surface deput, where you, Therein, the part between the same read there the part has to make	A processing station

Feature	Function	Description
Easy Arrange	Overlap transparent borders	<ul> <li>Enable the feature to allow application snap side by side without gap.</li> </ul>
	Hold down the SHIFT key to enable zone positioning	<ul> <li>Enable the feature to require you to press the Shift key to activate the Easy Arrange positioning.</li> </ul>
	Application Window Snap	<ul> <li>Quick access to snap application window to recently-used layout.</li> </ul>
	Span multiple monitors	<ul> <li>If you are using multiple monitors in an array or matrix, the <b>Easy Arrange</b> layout can be applied across all the monitors as one desktop. You need to align your monitors properly to make it effective.</li> </ul>
Enhanced Easy	Custom layouts	<ul> <li>Save and name five customized Easy Arrange patterns.</li> </ul>
Arrange		<ul> <li>Configure x*y patterns.</li> </ul>
	Recently- used layouts	<ul> <li>Press Ctrl+Shift+7 to cycle among recently-used layouts.</li> </ul>
	On-the-fly partition resizing	<ul> <li>Move the mouse cursor to the layout pattern, right-click the mouse and select Customize Layout.</li> </ul>
		<ul> <li>Press and hold mouse left button to move border. The new layout will be saved after five seconds when the mouse left button is released.</li> </ul>
	Easy Arrange layouts for portrait mode	<ul> <li>Portrait mode Easy Arrange icons are presented when monitor is rotated.</li> </ul>

NOTE: If an application window cannot fit in the zone defined by Easy Arrange, the application may not display properly.

NOTE: Disable the Mac "Display have separate spaces" before using the Easy Arrange function.



# **Using Application Window Snap**

The **Application Window Snap** is designed to enable application placement on any screen quickly. When this function is enabled in Dell Display Manager, dragging the application triggers a floating menu that contains recently-used **Easy Arrange** layouts. Drop the application to any one of the listed layouts to perform window placement.

You can enable this feature by one of the following methods:

• Tick the option from the **Quick Settings** menu on the status bar.

			Cell Chiple	e Maria			
laded a place	Alian Alianta	Auto Misia Lutteri ettolo	the second for the		nand Marcigae tai: Dipitri Admin	Kipitote mis Kitiggéd ir	
	and an			-	= ==		
IL COLO							
							E .
To coost a su Descharter	atore has reacted to	ol, at sign of Sectors	Contraction (	ent they	sici lana Stanlastian i	and some	
Held down	19.34	T best for unhalted	ality of the second	-	And in the	Constant of the local division of the local	

Right-click on the DDM icon on the status bar and select **Application Window Snap** to enable the function.





•

### Managing multiple video inputs

The **Input Manager** tab provides convenient ways for you to manage multiple video inputs connected to your Dell monitor. This makes it easy to switch between inputs while you work with multiple computers.

All video input ports available to your monitor are listed. You can assign each input with a name. Save your changes after editing.

	Bell Dap	by Manager	
Ram Rampot 1897 (Solve) 197 1988 ( 1985)	And Hum Ang Ar		0
Faran Ad Ingust attaches Tepres English and attaches Physics	1447 1447 144 144 144 144 144 144 144 14	Deres of	

#### NOTE: Refer to your monitor's user guide for available inputs.

Assign shortcut keys for quick access to your favorite input and switch between two inputs. Alternatively, switch the input source from the menu drop-down list.

	Gref Danglay, Marlanger
Texture:	SC Auto Mode Grey Altrange College Options O
WERE SAMING	Q-==:
-	Q
ABATI	Queer une une
XOMIT	and and Orac
an saint an	a. 🔛 + + + + + + +
<b>Excite</b> input of	est les
have	et unet 🔒 Dargeation tant
ingent seitent abust	out www.
Nane	er upt. Something
15352	inter interior

#### Selecting PIP/PBP mode

1. Click on the **PIP/PBP mode...** (Picture-in-Picture/Picture-by-Picture) icon to enable the split screen function on supported models.

Auro Arro Auropet A All Charley	a munite – Banas Arr gan martes			0
Name (cont in the later) in the later of the	er se e	1.64 spenses	1 million de la companya de la compa	
HER C. (Autor)			Concert of	
and the second se		and the second se	0.64	
1970		Coleman 1	alalas vent	
1001	1000	Come	HERE AND	
10081		100001	Inter Oriest	
	<b>R</b>	000 uliant		
Parte	H-100-6	8	Zherge average	eid l
Separate and the standard and		- 22		
Page 1	*** 388-5"	<b>B</b> 4	OF OF	- 10
		100		= T

2. Select a target window size to split the screen to suit your need.

	97	d Display Mahageri	200 AM \$255	
Num port	Bott Automate 3 Epullative	taas ketoropa <b>20111</b> Udd garden	Comons an pior	0
160 C Owner			0	
100		0	and the second	
rankt	10.0	Sec. 1		
-				-
Family Sign	a anamou hay			
Here	(++), 146	e 🛛 🗎	Charge on the	er hend
inger series	electricit has			
Hore	10 108	e. 🛛 🖥	Server i United	13

#### Setting up the KVM

For monitors that supports Kernel-based Virtual Machine (KVM) feature, click on the **KVM wizard** icon and follow the on-screen wizard flow to set up the devices connecting to the monitor.

	Del Dispi	ny Manager	
	hants david thanks . Party lars	ter Barrister oger	- 0
ARRY LINGTON	THE REAL	The group per	erc (
100		Dates atta	
10041	and and	Come men in	
10181	and a state of the	MART CHART OF	esc .
		vM mineret	
family rand at	united bay		
Here	H 108-0	E They	Look working
depend and diff who	and any		
Page 1	** 558.5	005 GB	

The on-screen wizard flow is illustrated in the following screenshots.

1. Select the number of sources your monitor is connected to.



2. Pair the input sources with USB connections and assign preferred names.



			Ord Disates Maringe		
	800	Auto Mode	Gee Mange	0.0	0 10
ů	1		Sener the volue lags Sector ( Accepted lagrange)	A DAY COMMONS IN CHEMO IN INFORM	ACAS
-			10400114-128 (p)0 (005-20 (0108-0	nan part Lannaciae USB-00	L 1087
			(10.000)	Sector.	(Dent)

20 Managing multiple video inputs



**3.** Select a preferred partition.

	Dell Display Manager
bet 4,0 Mos	Lany in temper Control of the Control of A later Management and Apply and PC or water of a later Management of the participant between any and pattern in the period. Subject the spec of patterns per paster
ter st	1 Nation Sector

21

4. Click Finish to save and exit KVM wizard.



NOTE: Dell Display Manager communicates with your monitor even when the monitor is displaying video from another computer. You can install Dell Display Manager on the computer you frequently use and control input switching from it. You may also install Dell Display Manager on other computers connected to the monitor.



### Applying energy conservation features

On supported Dell models, PowerNap energy conservation options are available in **Options** tab. You can choose to set the brightness of the monitor to the minimum level, or to put the monitor to sleep when the screen saver is activated.

		Dieli Dispitay Me	nger 👘	
	na interferen	fair integer	Trans Manager	
O Preserving of O Preserving Factors in	priseria Registramont in their sport Norther from process, where			Deliger
Program marity	d Her		Approximation Service	In the state of the second second
Ont-dath + D	54.4 March 199		0111-918-1-9	
Dany Arrange In	No street on any			
$0.044 \times 1007 \times 2$				
There exists	100 cardinale perto	11757-1081-15-0	10.000	
mo-37758				

DELI

#### Other shortcut keys

Assign shortcut keys for quick access to commonly-used features.



Feature	Function	Description
Shortcut Keys	Program shortcut key	<ul> <li>Quick access to open the <b>Quick Settings</b> dialog box.</li> </ul>
	Easy Arrange MRU shortcut key	<ul> <li>Cycle through the 6 recently-used window layouts.</li> </ul>
	PIP position shortcut key	<ul> <li>Quick access to apply the PIP sub position of the window position to Top-Left, Top-Right, Bottom- Right or Bottom-left.</li> </ul>
	Application Window Snap shortcut key	<ul> <li>Quick access to snap application window to recently-used layout.</li> </ul>



#### **Restoring application positions**

Dell Display Manager can help you restore application windows into their positions when you reconnect your PC to the monitor(s). Access this feature by rightclicking on Dell Display Manager icon in the notification tray.

Open Dell Display Manager Application Window Snep
Sava cutranti window layout Auto-restore window layout
Online documentation Check for new version
6it

If you choose **Auto-restore window layout**, your application windows' positions are tracked and remembered by Dell Display Manager. Dell Display Manager automatically places the application windows into their original positions when you reconnect your PC to your monitor(s).



To go back to a favorite layout, first select **Save current window layout** and then **Restore saved window layout**.



Dell

You may use monitors with different models or resolutions in your daily routine, and you may apply different window layouts on them. Dell Display Manager registers the monitor you have reconnected and restore application positions accordingly.

In case you need to replace a monitor in a monitor matrix configuration, you can save the window layout before replacement and restore the layout after a new monitor is connected.



NOTE: You should keep your applications running in order to benefit from this feature. Dell Display Manager does not launch applications.

# Troubleshooting

If Dell Display Manager does not work with your monitor, it will display the following icon and message in the status menu.



Click on the icon, Dell Display Manager shows a more detailed error message.



Please note that Dell Display Manager only works with selected Dell-branded monitors. If you are using monitors from other manufacturers, Dell Display Manager does not support them.

#### Dell monitors not supported by Dell Display Manager

Dell Display Manager may not work with the following monitors:

- Dell monitor models not included in Mac Dell Display Manager supported list.
   For more information, see http://www.dell.com/ddm
- Monitors and accessories not listed in Mac Dell Display Manager support list. Virtual and wireless monitors do not support DDC/Cl
- Mac models earlier than year 2018
- macOS earlier than 10.14

#### Unable to detect supported Dell monitor

If Dell Display Manager is unable to detect and/or communicate with a supported Dell monitor, please take following actions to troubleshoot:

- 1. Make sure the video cable or USB upstream cable is properly connected to your monitor and your computer. Ensure all the connectors are firmly inserted into the ports.
- **2.** If connecting HDMI cable not working, switch to use HDMI and USB upstream cable. Launch DDM again.
- 3. Check the monitor OSD to ensure **DDC/CI** is enabled.

- **4.** Remove any docking stations or cable extenders or converters between the monitor and the graphics port. Some low-cost extenders, hubs or converters may not support DDC/CI properly and can fail Dell Display Manager. Update the driver of such device if the latest version is available.
- 5. Restart your system.



# Updating Dell Display Manager software

If your PC is connected to the Internet, you will be prompted to upgrade to a newer version of Dell Display Manager when it is available. It is recommended to download and install the latest Dell Display Manager application.

You may also check for new version by right clicking on Dell Display Manager icon.





29